



Concord 4 Quick Reference Sheet

Disarming the System or Canceling an Accidental Alarm:	Press 1+Code
Arm to Stay (Level 2):	Press 2+Code
Arm to Away (Level 3)	Press 3+Code
Send a Police Alarm:	Hold down The A and 1 Buttons at the same time.
Send a Medical Alarm:	Hold down the B and 4 Buttons at the same time.
Send a Fire Alarm:	Hold down the C and 7 Buttons at the same time.
To arm your system silently:	Press 5+2+Code for Stay or 5+3+Code for Away
Checking System Status	Press the * Key
Turn the Chime Feature on or off:	Press 7+1
Turn Energy Saver Feature on or off:	Press 7+2
Check Alarm Memory:	Press 7+6
View Event History:	Press 8+Code+8

Auto stay arming: Your system will not arm to Level 3: Away if it does not recognize you have left the home. If the system does not see an Entry/Exit door open during the arming time down it will set the arming level back to Level 2: Stay.

Zone Bypassing: If the system shows an open zone it will protest the arming. The keypad will beep and read protest, to arm the system with the zone open press the “#” key labeled bypass. The system will arm, but the open zone will not be armed.

Dialer Abort: In order for your system to be SIA compliant it has a feature called Dialer Abort. This means you have a short grace period after the alarm goes off to input your code before the system reports an alarm.

Your alarm system has many other features and options. See your system’s users guide for full explanations. [If you have any questions about your system please call our service line 1-800-446-2400.](tel:1-800-446-2400)